



## ASSEMBLY DRAWING LIST



## RX200 PROFI three-point linkage

| Ser. No | Code    | Name & Specification | Quantity |
|---------|---------|----------------------|----------|
| 1       | 130237  | Linkage              | 1        |
| 2       | 130130  | Upper linkage pin    | 1        |
| 3       | 400034  | Lock pin 4.5         | 1        |
| 4       | W000026 | Washer M20           | 1        |
| 5       | B000097 | Bolt M14×40          | 4        |
| 6       | W000016 | Washer M14           | 8        |
| 7       | N000032 | Lock nut M14         | 4        |
| 8       | 130136  | Upper linkage parts  | 1        |
| 9       | 100002  | Hook                 | 1        |
| 10      | B000103 | Bolt M16×45          | 4        |
| 11      | W000017 | Washer M16           | 16       |
| 12      | N000033 | Lock nut M16         | 8        |
| 13      | B000213 | Bolt M16×55          | 4        |

## ASSEMBLY DRAWING LIST




### RX200 PROFI drive system

| Ser. No | Code    | Name & Specification        | Quantity |
|---------|---------|-----------------------------|----------|
| 1       | 130071  | Roller axis (Left)          | 1        |
| 2       | 130072  | Main roller bearing block   | 2        |
| 3       | 130073  | Paper washer                | 1        |
| 4       | 130238  | Main body (Left) side plate | 1        |
| 5       | W000001 | Spring washer M10           | 7        |
| 6       | B001235 | Bolt M10×22                 | 7        |
| 7       | 130074  | Special bolt M16×44         | 1        |
| 8       | W000005 | Spring washer M18           | 1        |
| 9       | W000015 | Washer M12                  | 6        |
| 10      | N000031 | Lock nut M12                | 6        |
| 11      | 130239  | Paper washer                | 1        |
| 12      | B001135 | Bolt M12×45                 | 6        |
| 13      | 130083  | Rubber seal 125×3.55        | 1        |
| 14      | 130240  | Middle gear axle            | 1        |
| 15      | 130241  | Middle gear                 | 1        |
| 16      | 130242  | Upper gear                  | 1        |
| 17      | 130088  | Special lock nut M35×1.5    | 1        |
| 18      | 130243  | Upper gear flange           | 1        |
| 19      | W000004 | Spring washer M16           | 1        |

| RX200 PROFI drive system |          |                              |          |
|--------------------------|----------|------------------------------|----------|
| Ser. No                  | Code     | Name & Specification         | Quantity |
| 20                       | B001244  | Bolt M16×40                  | 1        |
| 21                       | B001345  | Bolt M6×20                   | 2        |
| 22                       | W000024  | Spring washer M6             | 6        |
| 23                       | 130244   | Gear cover gasket            | 1        |
| 24                       | 900067   | Oil plug M16×1.5             | 1        |
| 25                       | 900068   | Combination washer 16        | 2        |
| 26                       | 130245   | Gear cover                   | 1        |
| 27                       | 130095   | Lock nut M35×1.5             | 1        |
| 28                       | 900070   | Oil check plug M18×1.5       | 1        |
| 29                       | B002115  | Bolt M8×45                   | 4        |
| 30                       | W000021  | Washer M8                    | 44       |
| 31                       | N000039  | Lock nut M8                  | 22       |
| 32                       | 900071   | Oil drain plug M16×1.5       | 1        |
| 33                       | B002116  | Bolt M8×35                   | 18       |
| 34                       | 130101   | Rubber seal 42.5×2.65        | 1        |
| 35                       | S000020  | Circlip for hole 85          | 1        |
| 36                       | 130089   | Bearing 6209                 | 1        |
| 37                       | 130103   | Lower gear                   | 1        |
| 38                       | S000021  | Circlip for hole 110         | 2        |
| 39                       | 130146   | Lower gear sleeve            | 1        |
| 40                       | 130105   | Bearing 6310                 | 2        |
| 41                       | OS000111 | Oli seal 55×75×8             | 4        |
| 42                       | B000334  | Bolt M12×30                  | 6        |
| 43                       | 130112   | Roller axis (Right)          | 1        |
| 44                       | 130117   | Round plate sleeve from Axis | 1        |
| 45                       | W000002  | Spring washer M12            | 1        |
| 46                       | B000084  | Bolt M12×30                  | 1        |
| 47                       | 130120   | Paper washer                 | 1        |
| 48                       | 130122   | Bearing seat cover           | 1        |
| 49                       | 000094   | Grease Nipples M6            | 1        |
| 50                       | B000107  | Bolt M6×20                   | 4        |
| 51                       | W000025  | Washer M6                    | 4        |

## ASSEMBLY DRAWING LIST



### RX200 PROFI series

| Ser. No | Code    | Name & Specification    | Quantity |
|---------|---------|-------------------------|----------|
| 1       | 130147  | Support tube for RX200  | 1        |
| 2       | 130148  | U bolt 12×80            | 4        |
| 3       | W000017 | Washer M16              | 4        |
| 4       | W000004 | Spring washer M16       | 4        |
| 5       | B000102 | Bolt M16×40             | 4        |
| 6       | 130159  | Gearbox                 | 1        |
| 7       | N000035 | Lock nut M20            | 2        |
| 8       | 130026  | Cover spring            | 4        |
| 9       | 130027  | Cover mounting bracket  | 4        |
| 10      | W000014 | Washer M10              | 40       |
| 11      | B000078 | Bolt M10×40             | 6        |
| 12      | 130030  | Fixing the cover        | 2        |
| 13      | N000030 | Lock nut M10            | 20       |
| 14      | B000077 | Bolt M10×35             | 2        |
| 15      | 130036  | Cover mounting plate 1  | 2        |
| 16      | B000075 | Bolt M10×25             | 8        |
| 17      | 130035  | Round plate sleeve      | 2        |
| 18      | W000026 | Washer M20              | 2        |
| 19      | W000018 | Washer M22              | 4        |
| 20      | 130029  | Fixing the cover spring | 2        |

## RX200 PROFI series

| Ser. No | Code    | Name & Specification             | Quantity |
|---------|---------|----------------------------------|----------|
| 21      | 130037  | Cover mounting plate 2           | 2        |
| 22      | B000076 | Bolt M10×30                      | 4        |
| 23      | 130048  | Cover spread                     | 1        |
| 24      | 100003  | Lock pin                         | 4        |
| 25      | 500025  | Lower linkage pin                | 4        |
| 26      | 130049  | Lower linkage pin                | 2        |
| 27      | 400034  | Lock pin 4.5                     | 2        |
| 28      | B000098 | Bolt M14×45                      | 23       |
| 29      | W000016 | Washer M14                       | 44       |
| 30      | N000032 | Lock nut M14                     | 19       |
| 31      | W000003 | Spring washer M14                | 4        |
| 32      | 130067  | Adjust plate (connection)        | 2        |
| 33      | 130107  | Adjust plate (Left)              | 1        |
| 34      | N000031 | Lock nut M12                     | 136      |
| 35      | W000015 | Washer M12                       | 54       |
| 36      | B000086 | Bolt M12×40                      | 4        |
| 37      | 130044  | Lower locking                    | 2        |
| 38      | 130056  | Side cover                       | 2        |
| 39      | 130057  | Round pipe plug                  | 4        |
| 40      | B000089 | Bolt M12×45 (12.9 Level)         | 8        |
| 41      | B000029 | Bolt M12×70                      | 4        |
| 42      | 130059  | Front shield (Left) for 160-200  | 1        |
| 43      | 130064  | Front shield (Right) for 160-200 | 1        |
| 44      | 130246  | Main roller for RX200            | 1        |
| 45      | B000185 | Bolt M12×35 (12.9)               | 108      |
| 46      | W000002 | Spring washer M12                | 114      |
| 47      | 130144  | Blade (Left)                     | 27       |
| 48      | 130145  | Blade (Right)                    | 27       |
| 49      | 130066  | Adjust plate (Right)             | 1        |
| 50      | B000085 | Bolt M12×35                      | 6        |
| 51      | 130247  | Main body (Right) side plate     | 1        |
| 52      | 500019  | Support foot                     | 1        |
| 53      | 000064  | Pin for support foot             | 1        |
| 54      | 000063  | R pin 3.5                        | 1        |
| 55      | 500018  | Support tube plug                | 1        |
| 56      | 130248  | Bracket for gearbox              | 2        |
| 57      | 130114  | PTO protection bracket           | 1        |
| 58      | B000254 | Cross recessed pan screw M8×16   | 3        |
| 59      | W000008 | Spring washer M8                 | 7        |
| 60      | W000021 | Washer M8                        | 7        |
| 61      | 130249  | Bracket for gearbox              | 2        |
| 62      | B000109 | Bolt M8×16                       | 4        |
| 63      | 000030  | Gearbox shaft cover              | 1        |
| 64      | 130250  | PTO Protection Plate             | 1        |
| 65      | 130018  | Cover spread                     | 1        |
| 66      | P000005 | Cotter pin 4×25                  | 2        |
| 67      | 130251  | Rear cover for RX200             | 1        |
| 68      | 400096  | Baffle shaft for 200             | 1        |
| 69      | 130253  | Main body for RX200              | 2        |
| 70      | 130180  | 05B800 PTO with clutch           | 1        |